



1

Set Temperature and time.

320F (160C) / 12-15 Seconds



2

Load a Test Tote Bag

If possible, slip the platen through the bag so there is only one layer of fabric on top. Otherwise, lay the bag on top of the platen. Avoid seams and gussets if possible.



3

Set Pressure.

- Manual Press: Tighten dial until the press won't close. Loosen dial progressively until the press closes. Unless pressure on polyester.
- Hotrontix and Geo Knight: 7-8
- Pneumatic Press: 35-40 PSI



4

Pre-Press: 5-8 Seconds

Prepressing releases moisture from the bag ensuring good contact. Repeat this step until there is no steam.



5

Place your Supacolour

Position your Supacolour transfer on the bag. Lay the teflon sheet or parchment paper over the Supacolour.



6

Press for 12 Seconds



7

Peel Immediately

Hot peel immediately from a corner in one smooth motion. Peel with confidence and without hesitation. Hold down bag with your free hand for better control.



8

Post-Press: 2 Seconds

Use a teflon sheet or parchment to seal the edges of the Supacolour.



SupaBill's SupaTips

- Always test press on a spoiled or old cotton bag to dial in your press before pressing your production.
- Supacolour always gives you spares so you can dial in your press.
- Supacolour not sticking when you peel? Increase pressure and peel quickly within 2 seconds of lifting press. keep transfer a clear distance from seams and gussets.
- Still won't peel easily? Repress for 4 seconds then try from a different corner.
- These instructions are your default starting point, settings may vary for different garments and presses.

Need help? - hello@supacolour.co.nz